

Instructions to clean the volume pot on the Acoustic Energy Aego 2 / Aego M

There are two ways to get switch cleaner into the volume pot.

1. Hold the silver volume control and pull upwards. This will expose the thread and nut. Undo the nut a turn and a half (DO NOT fully undo the nut). This should give you enough of a gap to spray the switch cleaner into the volume pot.
2. Remove the back panel by removing the screws (as indicated in the picture).



The following should only be carried out by a trained or competent technician. Acoustic Energy Loudspeakers accept no responsibility for any loss or damage whilst carrying out this procedure.